



## Check the PMT gain and ADC offset in the scanner

If PMT gain value is corrupt or 0, it can't amplify electric signal. It could cause the white images

If PMT gain value corrupt or 0, please send an email to service1@digiray.co.kr.

_				51
Readonly paramete	rs	Editable pa	1	
Model	FireCR Dental	Nick	microsdmode	
H/W	1.0.0.1	PMT Gain	85	
B/L	1.0.1.99	ADC Offset	-17	
APP	1.0.1.99	DHCP	Yes	
PN		IP address	192.168.1.171	
MAC	8C:4B:59:11:16:51	Subnet Mask	255.255.255.0	
Mode	USB Mode	Gate Way	192. 168. 1. 1	
Calibration / Res / IP	Y / HD / None	M/C Str	128	
Temp Main/Front/Laser	29.1/32.3/33.0 ℃	M/C Nor	17	
RPM	2400	0×108	0	set register
LPeak	60009	Edit parameters Reset Scanner Save Params RPM Monitor		
RPeak	60010			
RFID	0	Reset Scanner	Save Params	RPM Monitor
Gain(R)	85			
Offset(R)	-17			




## Measure the High voltage generator voltage

Measure the voltage DC on a Main board during scanning only.

Measured voltage can be varied depending on the PMT gain value.

• Threshold: -350 < Measured voltage <-650



## PMT assembly

Please refer to the FireCR Dental service manual for PMT replacement.

