

The procedures on how to adjust the Ejector guide

1. Remove the Front Cover and Top Cover, and then you can access to the ejector guide.
2. Adjust the “Ejector guide” using tool toward the back of dental or front of the dental like below picture.

